




Toothpick Miniatures

by Alexandre Karadimas


Make your own 1:64 miniatures with common household tools and materials

Pak 36





Download this booklet and others for free from <http://www.toothpick-miniatures.com>
Visit the Youtube channel: <https://www.youtube.com/@ToothpickMiniatures-wl7gf>

Booklet 6 version 1 – Pak 36 and variants – March 2025




(1) Thin Kraft paper can be found in paper bags for fruits & vegetables. (2) Smooth paper can be found in leaflets and magazines. (3) Rigid Paper can be found for instance in train tickets and magazine covers, it can retain its shape when folded.




Rigid Paper is made of a single layer (4) whereas cardboard (5) is made of several layers that come apart when bent.



(3) Ø 0,3 mm thin wire is typically sold as "florist wire" or "jewelry wire".
(4) Ø 0,25 mm thin plastic-wrapped "freezer" wire can substitute for thin wire.



(2) This design uses paper stems of ear cleaning swabs ("Q-tips"). It is necessary to use a variety that has a **hole** in its center (1). Note that different varieties have been marked differently (2) so that the workshop's materials supply remains manageable.



(5) Q-tips stems are a tight roll of paper. Conical shapes can be made by pushing in the center with a nail or a similar object.




Some parts have a simple design and are best draw in batches, using a ruler. Several examples are shown in the Steps illustrations.

Other parts have a complex design, which would be too time-consuming to draw from

scratch. In these cases we will first make a **template**, a piece of cardboard with all the markings needed to replicate these parts, as well as indications to modify and position them precisely afterwards.


P01 How to make templates

1. On a white piece of cardboard, draw a rectangular frame and write the measures on all sides.




2. Use these marks as a grid to position points of the template. Draw the template.
3. Pierce the points as indicated then cut to shape.
4. Label the template. Draw the location of the folding lines with a distinct colour, also mark "special" dots.

First pierce with the Ø 0,4 mm pin then use the Ø 0,6 mm pin and wiggle it so the Ø 0,7 mm graphite tip of the mechanical pencil can get through.




Most templates are on page 6.

P02




Tires are built by glueing strips of cardboard into a spiral.

1. For both ends of the strip, shave off about 1 mm from the smooth side, in order to avoid a visible "step" where the strips ends.



2. Coil the strips around a pen to give it a shape.










3. Start by glueing a portion of the strip to the wheel rim, so you can position it precisely at the depth you want. Let the glue harden.



4. Glue the rest of the strip in a spiral, all at once. While the glue is still fresh, apply pressure on the spiral or rub it against a flat surface, so that the outward side has an even aspect.



Part A - Carriage & wheels





Part B - Gun & shield

Part C - Painting



Pak 36
Templates
Scale 1:64
Page 1/1

Flip it along this side










+ Pierce for 0,7mm

⊕ Special purpose

— Folding line

↙ Connect to symmetrical counterpoint


RC: Regular Cardboard
RP: Rigid Paper



Diagrams on this page are not all at the same scale

B04


You can use an **elevated recuperator** for the infantry guns.





Note: you can use leftovers to build straight recuperators with them.

Glue two smaller pieces of cardboard together (in a stacking order) and use the template on it.

The pencil line is around 0,7 mm wide, comparable to the thickness of DWC wire, so if you place the piece on either side of the line you will have a gap within specifications.






The rest of the procedure is as in the step B03.


**B05****Trunnion**

(1) Glue the triangular parts to a larger piece of cardboard so that a small band of about 1 mm remains free. This will create a visual gap between the trunnion and the recuperator.

Cut off the **trunnion** triangular parts as depicted. Place a dot on a lower corner to differentiate between left side and right side.

**B06****Trunnion positionning**

(1) Glue the trunnions so that their rear side is at the level of the back of the axle hole. The trunnion parts align on the bottom of the recuperator piece.



For the elevated recuperator, draw a line 3 mm from the bottom and parallel to it. Remove this part.




This is how the elevated recuperator piece should be positioned on the carriage.

Here as well, glue the trunnions so that their rear side is at the level of the back of the axle hole. The trunnion parts align on the bottom of the recuperator piece (2).

B07**Controls and sights**

Roll a 15 x 10 mm piece of smooth paper into a cylinder about 1,5 to 2 mm of diameter.




Cut about a 45° angle from the 10 mm marking as depicted.

(2) Glue the smaller part at an angle. (1) Slide the sights between the trunnion and the recuperator.




Sights: cut a 6 x 1,5 piece of regular cardboard and cut one end at a 45° angle. Glue a strip of thin kraft paper to it, trim the width to fit, use it to glue a 3 mm piece of DWC wire to its (smooth, not porous) side.





Flatten at 5 mm from the tip and glue to the left hand side trunnion so that the other end is at the level of the recuperator's back.

Finally, cut slices off a Q-tip stem, about 0,5 to 1 mm thick. (3) Glue them to the ends of the cylindric pieces.



(4) Use the positioning dots to draw two perpendicular lines to line (1). Draw two parallel lines 0,5 mm and 2,5 mm from line (1), cut away the rectangle.






Start to connect the dots from the outside inwards. In order to keep the template easy to use, two points have to be made manually. The points (3) is located where the lines (1) cross line (2).

Draw a circle about 3 mm in diameter around the two "special purpose" dots (you can use the stem of a Q-tip as a guide) then remove as pictured. Remember to spare the shield's bottom 1 mm band (5) when cutting the hole for the gun. (6) Cut the corners to give them a rounder shape.


B09

Apply glue on the external side of the trunnions then glue the shield to the gun assembly.




Optional: the Pak 36 can have two boxes on the inner shield, one 3 x 4 mm with its left side aligned to the center line (1) and another 3 x 2 mm box on the left hand side (2). To make these boxes, glue two thicker pieces of cardboard together and cut out a 3 mm strip (3), then cut to size.

For the elevated recuperator assemblies, it may be necessary to cut off the pointy ends of the trunnions.


B10**M1943 shield**

For the **M1943 sights**, cut a piece of rigid paper as depicted.

Cut half of the base for the 6mm part and fold it 90°.



Use a Q-tip stem to roll and glue the 14 mm part onto itself.



6

3

14

1

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1

3

6

14

1